
ON
when
BRIGHT
switch
+
2 x Launchpad
Batteries (for brighter lights)
signal
ON
when
DARK
LIGHT SENSOR WITHOUT
A MICROCONTROLLER